

## 1 Type X Running Tools

**Type X Running Tool** is designed to run and set Type X or Type XN Lock Mandrel in the corresponding Landing Nipple in the well. It comes in 2 settings: selective and non-selective. When runs in selective setting, it can be run pass Nipples and selectively choose which nipple to set the Lock Mandrel. For non-selective setting, the lock is usually set on the highest nipple profile in the tubing or the bottom No-Go Nipple profile.

Type X Running Tool is used in conjunction with Type X Lock Mandrel. Please refer to Type X Lock Mandrel for more information.

## Available tool sizes as shown. Please contact our sales office for further enquiries.

To Suit Lock Mandrel Size	Tools O.D.	Fishneck O.D.	Top Connection	Bottom Connection
1.875"	1.772"	1.375"	15/16" -10UN	1/2" -13UN
2.313"	2.209"	1.750"	15/16" -10UN	5/8" -11UN
2.750"	2.720"	2.313"	1 1/16"-10UN	3/4" -10UN
2.813"	2.720"	2.313"	1 1/16"-10UN	3/4" -10UN
2.875"	2.840"	2.313"	1 1/16"-10UN	3/4" -10UN
3.313"	3.250"	2.313"	1 1/16"-10UN	13/8" -12UN
3.813"	3.750"	2.313"	1 1/16"-10UN	2 1/8" -12UN
4.313"	4.280"	2.313"	1 1/16"-10UN	2 1/8" -12UN
4.562"	4.500"	3.125"	1 1/16"-10UN	2 1/2" -10UN

**Toolstring Equipment** 



www.wellservpec.com